Thank You!

The following is helpful information about your LQ-570+ printer!

Thank you for buying an Epson printer, the smart choice in dot-matrix and laser printers. As part of our commitment to quality and service, we've included this Epson Printer Accessories Sheet for your information and convenience.

Epson printer parts and accessories are designed and manufactured specifically for Epson printers. Genuine Epson Consumables are an important part of Epson printers, not just supply items. They're manufactured with the highest grade plastics, nylons and special printhead lubricating inks, ensuring consistent print quality which allows the last character of the specification life to be the same as the first character printed. No other parts and accessories can deliver the same high-quality and guaranteed compatibility.

The following are available parts and accessories for your LQ-570+ printer:

Product	Product Code	Suggested Retail Price
LQ-570+		
Push/Pull Tractor Unit	*C800191*	*$ 64.00*
Standard Capacity Cut Sheet Feeder	*C806371*	*73.00*
High Capacity and Envelope Cut Sheet Feeder	*C806381*	*192.00*
Film Ribbon	*7768*	*12.00*
Fabric Ribbon	*7753*	*7.00*
Fabric Ribbon Replacement Pack	*7755*	*6.50*
Interfaces for LQ-570+		
Serial Interface Board	*C823051*	*88.00*
Serial Interface with 32KB Buffer	*C823071*	*152.00*
Parallel Interface with 32KB Buffer	*C823101*	*152.00*
Coax Interface	*C823141*	*699.00*
Twinax Interface	*C823151*	*669.00*
Parallel Cable	*C1-9E-A*	*29.00*

How to order: You can buy Epson Accessories at your Epson dealer or you can order by phone. Credit card payments are welcome when ordering through Epson.

USA: For nearest dealer call **1-800-289-3776**; To order by phone call **1-800-873-7766**
Canada: For nearest dealer call **1-800-463-7766**; To order by phone call **1-800-873-7766**
Latin America: For nearest dealer and to order by phone call **1-305-265-0092**

EPSON®

Specifications are subject to change without notice. Epson is a registered trademark of Seiko Epson Corporation.
All other product and brand names are trademarks and/or registered trademarks of their respective companies. © Copyright 1992 Epson America, Inc.

NOTICE



NOTE

To prevent damage during shipping, several pieces of protective material are packed with your printer. You must remove these before you assemble your printer.

NOTA

L'imballaggio della vostra stampante contiene molti elementi protettivi, per prevenire danni durante il trasporto. Non dimenticate di toglierli prima di iniziare a utilizzare la stampante.

HINWEIS

Zur Vermeidung von Transportschäden wurde der Drucker durch schützende Verpackungsteile gesichert. Diese Teile müssen vor dem Zusammenbau des Druckers entfernt werden.

NOTA

Para evitar daños durante el transporte, su impresora viene protegida por varias piezas de material protector. Debe retirar estas piezas antes de montar su impresora.

ATTENTION

Afin d'éviter tout dommage durant le transport, des matériaux de protection ont été emballés avec l'imprimante. Veillez à bien les retirer avant de l'installer.

Printed in Hong Kong 93. 10-100

4001750
C01-01